

TO AVOID SPLITTING FLANGES, START NAILS 1 ½" FROM END OF I—JOIST. NAILS MAY BE DRIVEN IN AT AN ANGLE TO AVOID SPLITING BEARING PLATE